




METEOR STORM DUAL MANUAL

The light is locked for shipment, refer to OPERATION instruction to unlock. Read this manual carefully before using and keep for future reference. Visit www.moon-sport.com for manual updates. The specifications and design are subject to change without notice.

CONTENTS



METEOR STORM DUAL



Optional accessories:
RB-28 (GOPRO MOUNT ADAPTER)
LX-BAT-3350 (LITHIUM ION BATTERY)

OPERATION




ON / OFF : Press 1s
MODE SELECT : Click
STEADY / FLASH : Press and hold 3s
BOOST MODE : Double click
LOCK/UNLOCK : 1. Power off
2. Press 8s: Locked
Unlocked

* Lock system: Lock the light to prevent accidentally turned on.
* Mode memory: The light resumes previous mode upon next usage.

MATRIX DISPLAY



MODES



BATTERY




CHARGING



DUAL COLOUR BEAM

Dual Colour beam is designed for multi-weather conditions.

BEAM COLOUR SELECT: Click



VARIABLE LUMEN SYSTEM



- Select desired mode.
- Press and hold to set lumen.
- Release when reaching desired lumen.

* Light flashes twice when reaching the MAX or MIN lumen level. CHANGING MAX or MIN

* Restore default mode: Press

* Mode memory: The light resumes previous VLS setting upon next usage.

RUNTIME

Natural White

	BOOST	MODE1	MODE2	FLASH1	STEADY FLASH	DAY FLASH	SOS
LUMEN	1300	800	100	100	200	400	-
H:MIN	2:00	3:00	25:00	125:00	49:30	220:00	91:00
VLS LUMEN	-	800-40	800-40	800-40	800-40	800-40	-
H:MIN	-	3:00-65:45	3:00-65:45	16:00-290:00	22:00-75:00	100:00-1000:00	-

Cool White Warm White

	BOOST	MODE1	MODE2	FLASH1	STEADY FLASH	DAY FLASH	SOS
LUMEN	800	600	80	50	100	200	-
H:MIN	2:45	3:30	27:30	250:00	77:30	400:00	170:00
VLS LUMEN	-	600-20	600-20	600-20	600-20	600-20	-
H:MIN	-	3:30-110:00	3:30-110:00	20:00-590:00	28:00-120:00	120:00-2000:00	-

OVERHEAT PROTECTION

The overheat protection device can ensure the bicycle light in a good running temperature condition, so that to protect the LEDs without burning case. If the light is in high temperature during operation, it will dim the light output.

CHARGING

- Power off.
- Plug USB cable to USB port.
- Unplug after fully charged.




* Do not charge over 5V.
* Keep away from flammable objects while charging.



BATTERY INSTALLATION



MOUNTING



WARNING

Understand country lighting laws and regulations before use. Do not shine light directly into eyes. Do not mount near wireless computer. Do not blind the oncoming vehicles, Always adjust the angle downward. Do not submerge the light into water. Keep light in cool and dry place when storing. Fully recharge the light at least every 3 months during storage.

WARRANTY

MOON Lights are covered by a **2-year LIMITED WARRANTY**, while MOON batteries are covered by a **180-day** warranty, both starting from the date of purchase.

This warranty covers defects or malfunctions arising from manufacturing or design flaws in the product. It does not cover normal wear and tear, non-rechargeable batteries, and damage caused by improper installation, misuse, mishandling, accidental loss, abuse, accidents, or negligence.

MOON may require the return of any product submitted for warranty consideration. Customers should contact their authorized local dealer or authorized regional distributor for warranty service.

For more information, please contact cs@moon-sport.com. ONLINE WARRANTY REGISTRATION Please visit www.moon-sport.com for online warranty registration.